


正面

(EN) ioplee	(EN) ioplee
Quick Guide	How to replace the pen tip?
Product model: IOEXTPENSILRT649	 Hold the pen barrel and turn the pen tip to the left to remove it.
Device Compatibility: Compatible for IOEXTPENSIL320BTR	 Attach the replacement pen tip to the tip of the pen barrel.
Product Size: 1.2*0.15*1.2cm (0.14cm±0.02cm)	 Hold the pen barrel and turn the replacement pen tip to the right to secure it in place.
Function: Writing and drawing	Be sure to use a screen protector on your iPad. *The illustration is for illustrative purposes only.
Body Materials: POM+copper	⚠ Safety and Handling
Package include: Replacement tip *4pcs Quick guide *1pcs Color box *1pcs	1. Keep the pen tip clean, as dust and other particles may cause excessive wear on the pen tip or damage the screen. 2. The pen tip will gradually wear out during use, and you will need to replace the pen tip to prevent damage to the screen. 3. The pen tip may pose a choking hazard to children or cause other personal injury. Keep them out of reach of children.
Batch No: 4512531751	

反面

(IT) ioplee	(IT) ioplee
Guida rapida	Come sostituire la punta della penna?
Modello del prodotto: IOEXTPENSILRT649	 Tenere il corpo della penna e ruotare la punta verso sinistra per rimuoverla.
Compatibilità del dispositivo: compatibile con IOEXTPENSIL320BTR	 Fissare la punta di ricambio della penna alla punta del corpo della penna.
Dimensioni del prodotto: 1.2*0.15*1.2cm (0.14cm±0.02cm)	 Tenere il corpo della penna e ruotare la punta di ricambio verso destra per fissarla in posizione.
Funzione: Scrittura e disegno	Assicuratevi di utilizzare una protezione per lo schermo sul tuo tablet. *L'illustrazione è a scopo illustrativo solo per scopi specifici.
Materiali del corpo: POM+rame	⚠ Sicurezza e maneggevolezza
La confezione include: Punta di ricambio *4 pezzi Guida rapida *1 pezzo Scatola colorata *1 pezzi	1. Mantenere pulita la punta della penna, poiché polvere e altre particelle potrebbero usurarla eccessivamente o danneggiare lo schermo. 2. La punta della penna si usurerà gradualmente durante l'uso e sarà necessario sostituirla per evitare danni allo schermo. 3. La punta della penna potrebbe rappresentare un rischio di soffocamento per i bambini o causare altre lesioni personali. Tenerli fuori dalla portata dei bambini.
Numero di lotto: 4512531751	