

ioplee

Manuale d'uso e
manutenzione



TOUCH SWITCH



RECHARGEABLE

ALU

ALUMINUM
COMPACT BODY



8-10 HOURS
WORKING TIME



BATTERY
LEVEL
DISPLAY

Matita universale - Argento

IOPEXTPENSIL320BTR

Gentile cliente,

Grazie mille per aver acquistato uno dei nostri prodotti. Vi preghiamo di leggere attentamente questo manuale di istruzioni e di conservarlo, in quanto fornisce informazioni preziose per un uso e una manutenzione sicuri.

INDICE


- 1 Avvertenze di sicurezza**
- 2 Descrizione dell'apparecchio**
- 3 Prima del primo utilizzo**
- 4 Funzionamento**
- 5 Pulizia e manutenzione**
- 6 Specifiche tecniche**
- 7 Smaltimento**
- 8 Garanzia e conformità**



1 Avvertenze di sicurezza

Tenere il prodotto lontano dal bambino per evitare che lo ingerisca o mangi inconsapevolmente.

2 Descrizione dell'apparecchio



- 1) Toccare due volte
l'interruttore
- 2) Porta di ricarica di tipo C
- 3) Luce C
- 4) Luce B
- 5) Luce A
- 6) Batteria integrata
- 7) Pennino rimovibile

3 Prima del primo utilizzo

Prima di utilizzare il mouse, leggere attentamente il manuale della matita e utilizzarlo in base ai requisiti e alle specifiche.

La tensione di carica deve essere di 5 V. Se la tensione di carica supera i 5 V, l'unità rischia di danneggiarsi e non è coperta dalla garanzia.

Suggerimenti utili


Dispositivi compatibili: Questa Stylus Pen supporta tutti gli schermi capacitivi (Si consiglia di aggiungere una pellicola temperata prima dell'uso per migliorare le prestazioni) Non supporta gli schermi elettromagnetici.

Questa penna stilo è compatibile SOLO con gli iPad rilasciati nel 2018 o successivamente.
M o d e l l i c o m p a t i b i l i: iPad 10th/9th/8th/7th/6th Gen, iPad Pro 11" (1st/2nd/3rd/4th), iPad Pro 12.9" (3rd/4th/5th/6th), iPad Mini 6th/5th Gen, iPad Air 5th/4th/3rd Gen.

*** * S i p r e g a d i a n d a r e s u**
[Setting>General>About] per confermare il
nome del modello del vostro iPad prima di
utilizzare. **NON** è compatibile con altri
modelli di iPad o con dispositivi touchscreen
di altre marche.

4 Funzionamento

1. Toccare due volte l'interruttore sulla parte superiore della penna, la spia si accende rapidamente.



Quando si tocca nuovamente l'interruttore, la luce si spegne. Se si smette di usarlo per più di 5 minuti, si spegne automaticamente per risparmiare energia.

2. Ora è possibile fare clic, scorrere ed eseguire altre operazioni su cellulari, tablet o computer portatili




utilizzando uno stilo al posto delle dita. Questo stilo è adatto alla maggior parte dei dispositivi con schermo capacitivo.

3. Design della punta della penna rimovibile e facilmente sostituibile, non c'è bisogno di preoccuparsi di usura e strappi. (Facile da rimuovere/installare la punta della penna).




Ricarica

1. Per la ricarica utilizzare il cavo di ricarica Type-C, collegando un'estremità alla porta Type-C dello stilo e l'altra alla porta USB del computer.



2. Collegare un'estremità del cavo adattatore al connettore Type-C della porta dello stilo e l'altra estremità a un adattatore da 5 V CC per la ricarica.



3. Collegare un alimentatore mobile da 5 V con porta USB Type-C direttamente allo stilo per la ricarica. La luce di ricarica blu lampeggia durante la ricarica, il tempo di ricarica completo è di circa 90 minuti.



Indicazione di carica

One lamp power display
5%-29%



Two lamp power display
30%-69%



Three lamp power display
70%-100%



5 Pulizia e manutenzione

- Spegnere la matita.
- Pulire la matita con un panno asciutto.

6 Specifiche tecniche

Numero di modello	IOPEXTPENSIL320BTR
Compatibilità dei dispositivi	Solo schermo capacitivo
Interfaccia di ricarica	Tipo C
Tempo di ricarica	1,5 ore
Peso	14±2g

7 Smaltimento

Trattamento di apparecchiature elettriche ed elettroniche a fine vita (applicabile nei Paesi membri dell'Unione Europea e in altri Paesi europei che gestiscono un sistema di raccolta differenziata).

Questo simbolo, apposto sul prodotto o sulla sua confezione, indica che il prodotto non deve essere trattato con i rifiuti domestici. Deve essere portato in un punto di raccolta dei rifiuti elettrici ed elettronici per essere riciclato e smaltito. Assicurando uno smaltimento appropriato di questo prodotto, contribuite anche a prevenire conseguenze potenzialmente negative per l'ambiente e la salute umana. Il riciclo dei materiali contribuisce a preservare le nostre risorse naturali. Per ulteriori informazioni sul riciclaggio di questo prodotto, contattare il comune, il centro di smaltimento rifiuti locale o il negozio in cui è stato acquistato il prodotto.



Ai sensi del Decreto Legislativo 14 marzo 2014, n. 49, "Attuazione della direttiva 2012/19/UE sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE)", il simbolo del cassonetto barrato sull'apparecchio o sulla sua confezione indica che il prodotto deve essere raccolto separatamente dagli altri rifiuti a fine vita. Pertanto, l'utente deve smaltire l'apparecchio a fine vita presso gli appositi punti di raccolta dei rifiuti elettronici ed elettrici o restituirlo al rivenditore al momento dell'acquisto di un nuovo apparecchio equivalente, su base individuale. Una corretta raccolta differenziata per il successivo smaltimento, il trattamento e lo smaltimento ecologico dell'apparecchio dismesso contribuisce a prevenire potenziali effetti negativi sull'ambiente e sulla salute e favorisce il riciclaggio dei materiali di cui l'apparecchio è composto. Lo smaltimento non autorizzato del prodotto da parte dell'utente può comportare l'applicazione delle sanzioni amministrative previste dalla normativa vigente.

8 Garanzia e conformità

La presente Garanzia loplee si applica solo ai prodotti loplee acquistati per uso personale e non a quelli destinati alla rivendita.

Il vostro prodotto loplee è garantito in conformità ai termini e alle condizioni della presente garanzia contro i difetti di fabbricazione e di conformità per un periodo di 2 anni, che decorre dalla consegna dell'articolo, se acquistato da un rivenditore ufficiale.

La garanzia non sarà valida se il prodotto è stato aperto, in presenza di danni fisici, di danni derivanti da uso improprio, da modifiche, da riparazioni effettuate da persone non autorizzate, da negligenza e nel caso in cui il prodotto sia stato utilizzato per scopi diversi da quelli per cui è stato concepito; inoltre, la garanzia legale non si applicherà se le modalità di acquisto o altre circostanze dimostrino, con ragionevole certezza, che l'acquisto stesso non è finalizzato esclusivamente al consumo privato.

Nel caso in cui il prodotto sia difettoso, è possibile restituirlo al rivenditore insieme a una descrizione del tipo di malfunzionamento, alla prova d'acquisto e a eventuali accessori.

Se il prodotto è ancora in garanzia, riceverete un prodotto sostitutivo (se disponibile) dal rivenditore.

La seguente casistica non è coperta da garanzia:

- Danni accidentali o derivanti da un uso scorretto o improprio, dal contatto con liquidi; danni causati da incidenti o eventi di forza maggiore come incendi, terremoti, inondazioni, atti vandalici, furti o altre cause esterne.
- Danni estetici come graffi, ammaccature o altre rotture di parti in plastica, causati da errori di manipolazione.
- Difetti derivanti dalla normale usura del prodotto (invecchiamento del prodotto).
- Incompatibilità con altri prodotti hardware/software non elencati nei requisiti minimi di sistema.

- Accessori di consumo come batterie, coperture protettive e fusibili, che normalmente si consumano nel tempo. Sono esclusi i problemi dovuti a non conformità relative alla manodopera o ai materiali.

In nessun caso il produttore sarà responsabile per danni incidentali o consequenziali, compresa la perdita di profitti commerciali o altri danni commerciali derivanti dall'uso del prodotto.

A causa della continua evoluzione tecnologica dei prodotti, i dati contenuti nel presente manuale possono subire leggere modifiche senza preavviso da parte del produttore.



Made in China



Dear Customer,

Thank you very much for purchasing one of our products. We kindly ask you to read this instruction manual carefully and to keep it, as it provides valuable information regarding the safe use and maintenance.

INDEX


- 1 Safety Warnings**
- 2 Description of the Appliance**
- 3 Before first use**
- 4 Operation**
- 5 Cleaning and maintenance**
- 6 Technical Specification**
- 7 Disposal**
- 8 Warranty and Compliance**



1 Safety Warnings

Keep the product away from the baby to avoid swallowing or eating unconsciously.

2 Description of the Appliance



- 1) Double Tap the Switch
- 2) Type- C Charge Port
- 3) C Light
- 4) B Light
- 5) A Light
- 6) Built in battery
- 7) Removable Nib

3 Before first use

Before using the mouse, carefully review the pencil manual and operate it according to its requirements and specifications.

The charging voltage should be 5V. if the charging voltage exceed 5V, the unit will be risk to damage and this will not be covered by the warranty.

Useful Tips


Compatible devices: This Stylus Pen supports all capacitive screens (It is recommended to add a tempered film before use for improved performance)
Does not support electromagnetic screens.

This Stylus Pen is ONLY compatible with ipads released in 2018 or Later. Compatible Models: iPad 10th/9th/8th/7th/6th Gen, iPad Pro 11" (1st/2nd/3rd/4th), iPad Pro 12.9"(3rd/4th/5th/6th), iPad Mini 6th/5th Gen, iPad Air 5th/4th/3rd Gen.


****Please go to [Setting>General>About] to confirm your iPad's model name before using. NOT Compatible with other ipad models or any other brand touchscreen devices**

4 Operation

1. Double-tap the switch on the top of the pen, the indicator light will light up quickly. When you double-tap the switch again, the light will be off. If you stop using it for more than 5 minutes, it will shut down automatically to save power.



2. Now you can click, slide and do other operations on mobile, tablet or laptop computer by using a stylus instead of your fingers. This stylus is suitable for the most capacitive screen devices.



3. Removable and easily replaceable pen tip design, no need to worry about wearing and tearing. (Easy to remove/install the pen tip).




1. Charging

Please use Type-C charging cable to charge, connect one end to the Type-C port of the stylus and the other end to the USB port of the computer.



2. Connect one end of the adapter cable to the Type-C connector of the stylus port of the stylus and the other end into a 5V DC current adapter for charging.



3. Plug a 5V mobile power with Type-C USB port directly into the stylus for charging. Blue charging light will flash when charging, the whole charging time is about 90 minutes.



Indicazione di carica

One lamp power display
5%-29%



Two lamp power display
30%-69%



Three lamp power display
70%-100%



5 Cleaning and Maintenance

- Turn off the pencil.
- Clean the pencil with dry wipe.

6 Specifiche tecniche

Model number	IOEXTPENSIL320BTR
Capacitive screen only	Capacitive screen only
Charging interface	Type C
Charging time	1.5 hour
Weight	14±2g

7 Disposal

Processing of electric and electronic equipment at the end of their service life (applicable in member countries of the European Union and other European countries operating a selective waste collection system).

This symbol, affixed to the product or its packaging, indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By ensuring the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the product was purchased.



In accordance with Legislative Decree of March 14, 2014, No. 49, "Implementation of Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE)" the crossed-out wheeled bin symbol on the appliance or its packaging indicates that the product must be collected separately from other waste at the end of its life. Therefore, the user should dispose of the end-of-life appliance at the appropriate collection points for electronic and electrical waste or return it to the retailer when purchasing a new equivalent appliance, on a one-to-one basis. Proper separate collection for the subsequent disposal, treatment, and environmentally friendly disposal of the discarded appliance helps to prevent potential negative effects on the environment and health and promotes the recycling of the materials the appliance is composed of. Unauthorized disposal of the product by the user may result in the application of administrative sanctions provided by current regulations.

8 Warranty and Compliance

This IOPLEE Warranty applies only to IOPLEE products purchased for personal use and not those intended for resale.

Your **IOPLEE** product is warranted in accordance with the terms and conditions of this warranty against defects in workmanship and conformity for a period of a 2 years, and that period begins upon delivery of the item, if purchased from an official dealer.

The warranty will not be valid if the product has been opened, in the presence of physical damage, damage resulting from incorrect use, modifications, repairs by unauthorized persons, negligence and in the event that the product has been used for purposes other than those for which it was intended; furthermore, the legal guarantee will not apply if the purchase methods or other circumstances demonstrate, with reasonable certainty, that the purchase itself is not exclusively aimed at private consumption .

In the event that the product is defective, it can be returned to the retailer along with a

description of the type of malfunction, proof of purchase, and any accessories.

If the product is still under warranty, you will receive a replacement product (if available) from the dealer.

These are not covered by the warranty:

- Accidental damage or damage resulting from incorrect or improper use, contact with liquids; damage caused by accidents or force majeure events such as fire, earthquake, flood, vandalism, theft or other external cause.
- Cosmetic damage such as scratches, dents, or other breakage of plastic parts, caused by handling errors.
- Defects resulting from normal product wear and tear (product aging).
- Incompatibility with other hardware/software products not listed in the minimum system requirements.
- Consumable accessories such as batteries, protective covers, and fuses, which normally wear out over time. Problems due to noncompliance related to labour or materials are excluded.

In no event shall the manufacturer be liable for incidental or consequential damages, including any loss of business profits or other commercial damages resulting from the use of the product.

The benefits conferred by this manufacturer's warranty are in addition to the rights provided by consumer protection legislation.

Due to the rapidly evolving nature of our products, the content of this manual may be subject to change without prior notice.



Made in China



ioplee

Prodotto e importato da Exertis Supply
Chain Services Limited.
Unità 21 Fonthill Business Park, Clondalkin.
Dublin 22, D22 FR82, Dublino, Irlanda

Manufactured and imported by Exertis Supply
Chain Services Limited.
Unit 21 Fonthill Business Park, Clondalkin.
Dublin 22, D22 FR82, Dublin, Ireland

"IOPLEE", marchio utilizzato su licenza Unieuro
"IOPLEE" used under license from Unieuro